



Your MG2000™ Gauge Package comes equipped with factory recommended settings and displays. No modifications are necessary. For advanced and custom settings, refer to your owner's manual.

## ALARMS



To silence an alarm, press and hold "M"  on the Tachometer until the alarm is silenced.

An alarm will continue to reappear until the condition has been corrected. For details on alarms, including User Defined Alarms, refer to your Owner's Manual.




## NOTES

1. Some discoloration or "blackening" of the LCD may occur if the MG2000 is in direct sunlight for a prolonged period. If this occurs, simply use the contrast adjustment to enhance the visibility of the LCD.
2. Certain polarized sunglasses will cause the LCD display to seem to disappear. If this happens, remove your polarized sunglasses and use the contrast adjustment to increase the visibility of the LCD.
3. Use only soap and water when cleaning your MG2000 instruments. Certain chemical cleaners will damage the fog-resistant lens on your instruments.




### Scrolling - Normal Operating Mode

 or 	Scrolls through your active displays
---	--------------------------------------












### Instrument Lighting (in Tachometer only)

	Press "M" mode button once to enter Lighting mode.
	Increases Lighting
	Decreases Lighting
The MG2000 will return to the Default screen/ Scrolling mode after 10 seconds of inactivity.	








### LCD Contrast

	To switch to Contrast mode press the "M" Mode button once if in Lighting mode (Tach Only) or Normal mode (Speedo Only). If in Normal mode (Tach Only) press mode button twice.
	Increases LCD contrast Press and hold to invert LCD color
	Decreases LCD contrast Press and hold to invert LCD color
The MG2000 will return to the Default screen/ Scrolling mode after 10 seconds of inactivity.	









### Edit / Set-up Mode

 and 	Hold "M" mode and "Up" (2 Sec) buttons together to enter Edit mode.
 or 	Scrolls through your available options.
 and 	Hold the "Up" and "Down" buttons (2 Sec) to select the item to be adjusted
 or 	Press the "Up" or "Down" button to make changes.
 and 	Hold the "Up" and "Down" buttons (2 Sec) to save changes.
	Press the "M" Mode button to return to the Previous Menu.
The MG2000 will return to the Default screen/ Scrolling mode after 20 seconds of inactivity.	













### Fuel Flow (in Tachometer only)

To achieve the most accurate Fuel Flow calculations, the following steps are <b>recommended</b> after each refueling.	
 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "RESET FUEL USED"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "RESET FUEL DONE."

### If Tank is refilled to 100% Full

 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "SET FUEL TANK FULL"
 and 	Hold "Up" and "Down" (2 Sec). The Horn will beep.
	Press the "M" Mode button twice to return to the Normal mode.

### If Tank is NOT refilled to 100% Full

 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "SET AMOUNT OF FUEL" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "FUEL AMOUNT X.X.L."
 or 	Use to input TOTAL amount of fuel in tank. (TOTAL amount of fuel is the amount of fuel remaining PLUS the amount of fuel added.)
 and 	Hold "Up" and "Down" (2 Sec). To save changes.
	Press the "M" Mode button twice to return to the Normal mode.

The MG2000 will return to the Default screen/ LCD Contrast mode after 10 seconds of inactivity.



Your MG2000™ Gauge Package comes equipped with factory recommended settings and displays. No modifications are necessary. For advanced and custom settings, refer to your owner's manual.

## ALARMS



To silence an alarm, press and hold "M"  on the Tachometer until the alarm is silenced.

An alarm will continue to reappear until the condition has been corrected. For details on alarms, including User Defined Alarms, refer to your Owner's Manual.




## NOTES

1. Some discoloration or "blackening" of the LCD may occur if the MG2000 is in direct sunlight for a prolonged period. If this occurs, simply use the contrast adjustment to enhance the visibility of the LCD.
2. Certain polarized sunglasses will cause the LCD display to seem to disappear. If this happens, remove your polarized sunglasses and use the contrast adjustment to increase the visibility of the LCD.
3. Use only soap and water when cleaning your MG2000 instruments. Certain chemical cleaners will damage the fog-resistant lens on your instruments.




### Scrolling - Normal Operating Mode

 or 	Scrolls through your active displays
---	--------------------------------------












### Instrument Lighting (in Tachometer only)

	Press "M" mode button once to enter Lighting mode.
	Increases Lighting
	Decreases Lighting
The MG2000 will return to the Default screen/ Scrolling mode after 10 seconds of inactivity.	








### LCD Contrast

	To switch to Contrast mode press the "M" Mode button once if in Lighting mode (Tach Only) or Normal mode (Speedo Only). If in Normal mode (Tach Only) press mode button twice.
	Increases LCD contrast Press and hold to invert LCD color
	Decreases LCD contrast Press and hold to invert LCD color
The MG2000 will return to the Default screen/ Scrolling mode after 10 seconds of inactivity.	









### Edit / Set-up Mode

 and 	Hold "M" mode and "Up" (2 Sec) buttons together to enter Edit mode.
 or 	Scrolls through your available options.
 and 	Hold the "Up" and "Down" buttons (2 Sec) to select the item to be adjusted
 or 	Press the "Up" or "Down" button to make changes.
 and 	Hold the "Up" and "Down" buttons (2 Sec) to save changes.
	Press the "M" Mode button to return to the Previous Menu.
The MG2000 will return to the Default screen/ Scrolling mode after 20 seconds of inactivity.	













### Fuel Flow (in Tachometer only)

To achieve the most accurate Fuel Flow calculations, the following steps are <u>recommended</u> after each refueling.	
 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "RESET FUEL USED"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "RESET FUEL DONE."

### If Tank is refilled to 100% Full

 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "SET FUEL TANK FULL"
 and 	Hold "Up" and "Down" (2 Sec). The Horn will beep.
	Press the "M" Mode button twice to return to the Normal mode.

### If Tank is NOT refilled to 100% Full

 and 	Press the "M" Mode and "Up" buttons together to enter the "Edit" mode. "LOCAL FUEL CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "TANK 1 CONFIG"
 and 	Hold "Up" and "Down" (2 Sec). The LCD window will read "SET AMOUNT OF FUEL" Hold "Up" and "Down" (2 Sec)
	Scroll down until the LCD window reads "FUEL AMOUNT X.X.L."
 or 	Use to input TOTAL amount of fuel in tank. (TOTAL amount of fuel is the amount of fuel remaining PLUS the amount of fuel added.)
 and 	Hold "Up" and "Down" (2 Sec). To save changes.
	Press the "M" Mode button twice to return to the Normal mode.

The MG2000 will return to the Default screen/ LCD Contrast mode after 10 seconds of inactivity.